


Step 1: Ensure there is Power supply and UPS is connected to Power Supply. The UPS should be in Standby mode, do not turn on the UPS.


Step 2: Ensure the Net Framework 3.5 is enable.

To enable, please go to Control Panel → Turn windows features on or off → Check box NET Framework 3.5



Step 3: Unzip and Install Bootloader software AS0220AD into the PC

Step 4: Run the Bootloader software. Select Model “Glamor”.



Step 5: Please follow the procedures as below and do the programming.

Step 6: Under Device, Select USB or RS232 connection

Step 7: Unzip the file "GR512128"

Step 8: Open File and select GR512128.ecy

Step 9: Click Program

Step 10: Completed, the new firmware is successfully write into the UPS.

